

COMPONENTS LIST

Not to Scale



3-Way Boss
A-05964



4-Way Boss
A-05965



3-Way Boss Top Cap
A-06811



4-Way Boss Top Cap
A-06814




Hip End Cap
A-05899



Rafter End Cap
A-05900



Glazing Retainer




LED Kit
5m: **A-06578**
10m: **A-06579**



Eaves Screw Cover



De-glazing Tool
A-05977



Eaves Corner Key
A-06762



Eaves Corner
Cups A
A-05896



Eaves Corner
Cups B
A-05897



Spring Clip
A-05817



Security insert
A-05976



Eaves Screw
A-05895



Eaves
Corner Screw
A-05894



Rafter Bolt
A-05957




Hip Adjuster
A-05905




Rafter Clamping Block
A-05898




Jack Rafter End Seal A
A-06729



Jack Rafter End Seal B
A-06730



Ridge Rafter
End Seal
A-06731



Jack Rafter Upper
End Seal RH
A-07493




Jack Rafter Upper
End Seal LH
A-07494




Ridge Rafter Upper
End Seal
A-07538

PROFILES


Not to Scale




Ridge Top Cap
A-05651




Rafter Top Cap
A-05650




Hip Top Cap
A-05649




Eaves Beam
A-05653




Thermal Cross Bar
A-05823




Glazing Retainer
A-05648



Rafter U-Channel
A-05655



Hip and Ridge U-Channel
A-05654



Eaves Screw Cover
A-05815



Glazing Retainer Isolator
A-05867



016 Glazing Retainer Seal
A-08359



016 Glazing Seal Upper (Hip/Rafter/Jack Rafter)
A-05806



016 Upper Glazing Seal (Ridge)
A-08358



016 Rafter Lower Seal
A-08271



016 Glazing Seal Lower (Hip/Ridge)
A-05803